Power Dual Pack
User's Guide

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net

dreamGEAR
www.dreamgear.net

Package Contents:
- 2-10ft Charge/Sync Cables
- User's Guide/Warranty Card
- Registration Card

Charge/Sync Cable
1. Plug the mini-USB side of the Charge/Sync Cable to your PS3 Controller.
2. Plug the USB side of the Charge/Sync Cable to any USB port on your PS3 (or any powered USB port).

NOTE: *Please refer to the User's Guide for your PS3 Controller for charging times.*

Contenido del Embalaje:
- Cables de carga/sincronización de 10 pies
- Guía de usuario/Tarjeta de garantía
- Tarjeta de registro

Cable de carga/sincronización
1. Enchufe el lado mini USB del cable de carga/sincronización a su controlador PS3.
2. Enchufe el lado USB del cable de carga/sincronización a cualquier puerto USB de su PS3 (o a cualquier puerto USB con alimentación).

NOTA: *Consulte la Guía de Usuario de su controlador PS3 para ver los tiempos de carga.*

Contenu de l'emballage :
- Câbles Charge/Sync 3 m
- Guide d'utilisation/Carte de garantie
- Carte d'enregistrement

Câble Charge/Sync
1. Branchez le connecteur mini-USB du câble Charge/Sync à la manette PS3.
2. Branchez le connecteur USB du câble Charge/Sync à un port USB de votre PS3 (ou tout port USB sous tension).

REMARQUE : *Reportez-vous au Guide d'utilisation de votre manette PS3 pour connaître les durées de charge.*